



Standard Programmable Thermostat

Homeowner's Guide / Installation, Start-Up, and Operating Instructions

Visit www.carrier.com

Homeowner's Guide




Fig. 1—Standard Programmable Thermostat

A99068

Programming and Operating Instructions

AT POWER UP

When power is first applied, AC or HP will appear for 5 seconds to tell you it is an air conditioner (AC) or a heat pump (HP) model. After this, the time display will flash to tell you the power has been off. The day and time will show, within 10 minutes, when the power went off. Pressing any button will stop the flashing.

SETTING THE CURRENT TIME:

1. Press the TIME/TEMP button. SET TIME flashes on the display.
2. Press the Up or Down button until the correct time is displayed.
3. To quickly advance to the proper time, press and hold the UP or DOWN button.
4. When the correct time appears on the display, press the HOLD/END button.
(Note: If you choose not to press the HOLD/END button, the thermostat will automatically exit the time setting mode after 10 seconds.)

SETTING THE CURRENT DAY:

1. Press the DAY button to advance to the correct day.

MANUAL OPERATION

TO OPERATE MANUALLY

(WITHOUT THE PROGRAMMED COMFORT SCHEDULE):

Press the HOLD/END button to make the HOLD icon appear. Then follow the four steps below:

1. To Select the Mode:

Use the MODE button to move between the choices. OFF, HEAT, COOL, or EMHT will appear on the display. EMHT will only appear on heat pump models.

2. To Select the Fan Operation:

Use the FAN button to move between continuous fan (indicated by the FAN ON icon) and auto fan operation.

3. To Read the Room Temperature:

The large display reads room temperature until a button is pressed.

4. To Adjust the Set Point:

The first press of the UP or DOWN button does not change the set point. It displays the current set point for a period of 5 seconds. Successive presses within this 5 seconds will adjust the set point and restart the 5 seconds. During the 5 seconds, the SET TEMP icon will be flashing.

PROGRAMMED OPERATION

Introduction: The Standard Programmable Thermostat provides four periods per day (MORNING, DAY, EVE, NIGHT) and two schedules per week (MoTuWeThFr and SaSu). A separate time, heat set point, and cool set point can be set for each period and schedule. Before starting to actually program the thermostat, fill out Table 1 with the values you wish to program. (The Energy Star, US Department of Energy recommended time and temperature values are already programmed for you as a starting point and are shown on the left side of the table.)

The first press of the PROGRAM button brings up the programming mode and places you at the current day and period. Successive presses move you between the four daily periods.

WHILE PROGRAMMING:

The TIME/TEMP button moves between selections of SET TIME, SET TEMP and HEAT, and SET TEMP and COOL. These three numbers are to be programmed for each of the periods MORNING, DAY, EVE, and NIGHT.

The DAY button moves between the weekdays, (MoTuWeThFr) and the weekend (SaSu) selections. A different schedule may be set for the weekdays and the weekend.

You may exit programming at any time by pressing the HOLD/END button.

Manufacturer reserves the right to discontinue, or change at any time, specifications or designs without notice and without incurring obligations.

PROGRAMMING A WEEKLY COMFORT SCHEDULE:

1. Press the PROGRAM button. The word PROGRAMMING appears on the display and the words SET TIME flash on the display. MoTuWeThFr or SaSu and the present period icons will appear on the display. The current mode (HEAT or COOL) will also show. Use the DAY button to select weekdays and the PROGRAM button to select MORNING.
2. Press the UP or DOWN button to set the start time for MORNING (box 1 value).
3. Press the TIME/TEMP button until COOL is on and SET TEMP flashes on the display.
4. Press the UP or DOWN button to select the cooling temperature set point (box 2 value).
5. Press the TIME/TEMP button until HEAT is on and SET TEMP flashes on the display.
6. Press the UP or DOWN buttons to select the heating temperature set point (box 3 value).
7. Press the PROGRAM button to advance to the next time period. Enter time and temperature settings from boxes 4 through 12 for the periods DAY, EVE, and NIGHT by following steps 2-6 above.
8. Press the DAY button to change between weekday and weekend programming. To set the weekend schedule, repeat steps 2 through 7, entering values in boxes 13 through 24.
9. Press END/HOLD to exit the programming mode.

MODIFYING YOUR WEEKLY COMFORT SCHEDULE:

If you choose to change any of your weekly schedule, press PROGRAM at any time. You will enter the programming schedule at the present day, present mode, but always in the morning period. You are ready to set the new starting time for the morning period. One press of the TIME/TEMP button and you are ready to set the new temperature. Press HOLD/END and you are finished.

OVERRIDING YOUR COMFORT SCHEDULE:

There are two ways to override your comfort schedule:

Method 1 — Manual Operation

By pressing the HOLD/END button to turn on the HOLD icon, the thermostat will maintain the current temperature settings and ignore the comfort schedule for an indefinite period of time. The word HOLD will appear in the display. Press the HOLD/END button a second time and the thermostat will return the temperature settings to the programmed comfort schedule. Pressing HOLD/END will not alter your programmed comfort schedule.

Method 2 — Temporary Override

At the first press of the UP or DOWN button, the current temperature setting will appear on the display. Pressing the UP or DOWN button again will temporarily change the set point as needed. At the next programmed time, the programmed comfort schedule will resume.

Table 1—Programming Table


ENERGY STAR FACTORY DEFAULT VALUES				NEW COMFORT SCHEDULE					
PERIOD	TIME	COOL	HEAT	MoTuWe ThFr TIME	COOL	HEAT	SaSu TIME	COOL	HEAT
MORNING	6:00 A.M.	78	68	1)	2)	3)	13)	14)	15)
DAY	8:00 A.M.	85	60	4)	5)	6)	16)	17)	18)
EVE	5:00 P.M.	78	68	7)	8)	9)	19)	20)	21)
NIGHT	10:00 P.M.	82	60	10)	11)	12)	22)	23)	24)

Installation, Start-Up, and Operating Instructions

NOTE: Read the entire instruction manual before starting the installation.

SAFETY CONSIDERATIONS

Read and follow manufacturer instructions carefully. Follow all local electrical codes during installation. All wiring must conform to local and national electrical codes. Improper wiring or installation may damage thermostat.

Recognize safety information. This is the safety-alert symbol . When you see this symbol on the equipment and in the instruction manual, be alert to the potential for personal injury.

Understand the signal words DANGER, WARNING, and CAUTION. These words are used with the safety-alert symbol. DANGER identifies the most serious hazards which will result in severe personal injury or death. WARNING signifies a hazard which could result in personal injury or death. CAUTION is used to identify unsafe practices which would result in minor personal injury or product and property damage.

INTRODUCTION

The Standard Programmable Thermostat is an electronic 24-vac, manual changeover wall mount thermostat. This thermostat uses two set points to maintain and control room temperature in both the heating and air conditioning modes. The thermostat is designed to maintain +/- 2°F accuracy. No batteries are required; temperature, fan, mode, and installer configuration settings are preserved with power off.

INSTALLATION CONSIDERATIONS

AIR CONDITIONER MODEL

The Standard Programmable AC (air conditioner) thermostat may be wired with or without connecting a common wire between the indoor equipment and the thermostat. However, it is recommended to use a common wire whenever possible. Without a common wire this thermostat becomes "power stealing." This means it will need to steal a small amount of power from the equipment to which it is connected. When "power stealing" connection is used, the supplied 270 ohm resistor must be connected at the indoor unit. (See Fig. 2, 3, and 5 and notes.)

NOTE: All Carrier equipment, with the exception of the Thermostat Conversion Kit, TSTATXXCNV10, is compatible with this thermostat in both power stealing and non-power stealing connections.

HEAT PUMP MODEL

The Standard Programmable HP (heat pump) thermostat is not power stealing and MUST have both R and C wires connected to operate properly. This thermostat uses a green LED to indicate auxiliary heat and emergency heat operation.

INSTALLATION

Step 1—Thermostat Location

Thermostat should be mounted:

- Approximately 5 ft (1.5m) from floor.
- Close to or in a frequently used room, preferably on an inside partitioning wall.
- On a section of wall without pipes or duct work.

Thermostat should NOT be mounted:

- Close to a window, on an outside wall, or next to a door leading to the outside.
- Exposed to direct light and heat from a lamp, sun, fireplace, or other heat-radiating object which may cause a false reading.
- Close to or in direct airflow from supply registers and return-air grilles.
- In areas with poor air circulation, such as behind a door or in an alcove.

Step 2—Install Thermostat

WARNING

Before installing thermostat, turn off all power to unit. There may be more than 1 disconnect. Electrical shock can cause personal injury or death.

1. Turn OFF all power to unit.
2. If an existing thermostat is being replaced:
 - a. Remove existing thermostat from wall.
 - b. Disconnect wires from existing thermostat, one at a time. Be careful not to allow wires to fall back into wall.
 - c. As each wire is disconnected, record wire color and terminal marking.
 - d. Discard or recycle old thermostat.

NOTE: Mercury is a hazardous waste and MUST be disposed of properly.

3. Separate front and back plastic assembly of thermostat.
4. Route thermostat wires through hole in mounting base. Level mounting base against wall (for aesthetic value only, thermostat need not be leveled for proper operation) and mark wall through 2 mounting holes.
5. Drill two 3/16-in. mounting holes in wall where marked.
6. Secure back plate to wall with 2 anchors and screws provided making sure all wires extend through hole in plastic.
7. Connect wires to proper terminal location on backplate.
8. Push any excess wire back into wall. Seal hole in wall to prevent air leaks. Leaks can affect thermostat operation. Any excess wire left inside thermostat casing may also affect thermostat operation by interfering with airflow across the temperature sensor.
9. Snap thermostat together making sure assembly is secure.
10. If "power stealing" connection is used, be sure to attach 270 ohm resistor at indoor unit. (See Fig. 2, 3, and 5 and notes.)
11. Turn ON power to unit.

On power up, depending on the thermostat model being used, the LCD readout will display either, AC for air conditioner model (1-stage heat/1-stage cool), or HP for heat pump model (2-stage heat/1-stage cool).

Step 3—Set Thermostat Configuration

Available thermostat configuration options and their numbers are:

- Option 1 -- Anticipator adjustment
- Option 2 -- Not available
- Option 3 -- Fahrenheit or Celsius operation
- Option 4 -- Enable fan (G) ON with heat (W)
- Options 5 through 9 -- Not available
- Option 10 -- O (reversing valve) On with Heat or Cool (present on Heat Pump model only)
- Options 11 and 12 -- Not available
- Option 13 -- Room temperature offset adjustment

An explanation for each configuration option is as follows.

TO ENTER THE CONFIGURATION MODE:

Press and hold FAN button for approximately 10 sec until room temperature disappears and the display reads "1" and is flashing. You are now in configuration mode.

NOTE: If HOLD/END button is pressed, or if no button is pressed for 3 minutes, the thermostat will exit configuration mode and return to normal operation. To re-enter configuration mode, the FAN button must be pressed and held for 10 sec again.

While in configuration mode, the following options are available:

Option 1—Anticipator Value Adjustment

This adjustment controls the sensitivity and cycle rate of the thermostat. Higher numbers decrease the cycle rate. Lower numbers increase the cycle rate. However, this feature will not allow more than 4 equipment cycles per hour (or 1 cycle every 15 minutes), regardless of setting. Values can range from 1 to 3. Factory default setting is 2. This default selection will provide optimum performance in nearly all installations. Try this setting first. Do not change setting unless there is evidence or need to do so. Unlike conventional anticipators, this setting is not to be determined by current draw. There is no need to measure, know, or compensate for current.

TO SELECT:

1. Enter configuration mode if not already there (see above).
2. Use UP and DOWN buttons to make the large (now flashing) display indicate 1.
3. Press the TIME/TEMP button once to flash the small display.
4. Use UP and DOWN buttons to move between 1, 2, or 3 on the small display. Factory default is 2.
5. Press TIME/TEMP button again to flash the large display for selection of another option, or press HOLD/END TO exit the configuration mode.

Option 3—Fahrenheit/Celsius Selection

This selection operates the thermostat in either Fahrenheit or Celsius.

TO SELECT:

1. Enter configuration mode if not already there (see above).
2. Use UP and DOWN buttons to make the large (now flashing) display indicate 3.
3. Press TIME/TEMP button once to flash the small display.
4. Use UP and DOWN buttons to move between F or C on the small display. Factory default is F.
5. Press TIME/TEMP button again to flash the large display for selection of another option, or press HOLD/END to exit the configuration mode.

Option 4—G (fan) ON with W (Heat) Selection

This selection determines whether G (fan) output is to be ON or OFF when W (furnace or strip heat) output is ON. Most furnaces and fan coils manage their own blowers and do not require a separate G signal. For these applications, select OFF. Some auxiliary heaters require a separate G signal from the thermostat to turn on the blower. In this case, select ON.

TO SELECT:

1. Enter configuration mode if not already there (see above).
2. Use UP and DOWN buttons to make the large (now flashing) display indicate 4.
3. Press TIME/TEMP button once to flash the small display.
4. Use UP and DOWN buttons to move between ON or OF (off) on the small display. Factory default is OF (off).
5. Press TIME/TEMP button again to flash the large display for selection of another option, or press HOLD/END to exit the configuration mode.

Option 10—O (reversing valve) On with Heat or Cool Selection

This selection is only available on heat pump model thermostats. This selection determines whether the reversing valve is energized in the heating or cooling mode.

TO SELECT:

1. Enter configuration mode if not already there (see above).
2. Use UP and DOWN buttons to make the large (now flashing) display indicate 10.
3. Press TIME/TEMP button once to flash the small display.
4. Use UP and DOWN buttons to move between H (energized in heating) or C (energized in cooling) on the small display. Factory default is C.
5. Press TIME/TEMP button again to flash the large display for selection of another option, or press HOLD/END to exit the configuration mode.

Option 13—Room Temperature Offset Adjustment

This option allows calibration (or deliberate miscalibration) of the room temperature sensor. There are various reasons why homeowners may want to have displayed temperature adjusted to a higher or lower value.

NOTE: Do not adjust for 30 minutes after installation because board may be heated by handling.

The selected number is the number of degrees, plus or minus, which will be added to actual temperature. The numbers can range between -5 and +5.

TO SELECT:

1. Enter configuration mode if not already there (see above).
2. Use UP and DOWN buttons to make the large (now flashing) display indicate 13.
3. Press the TIME/TEMP button once to flash the small display.
4. Use UP and DOWN buttons to move between -5 and 5 in 1 degree steps on the small display. Factory default is 0.
5. Press TIME/TEMP button again to flash the large display for selection of another option, or press HOLD/END to exit the configuration mode.

Step 4—Thermostat Operation

TEMPERATURE DISPLAY

Thermostat will display room temperature until UP or DOWN button is pressed. The words SET TEMP appear when these buttons are pressed and the current set point is displayed. If no buttons are pressed for 5 sec, the display will change back to show room temperature.

TIMEGUARD TIMER

A 5-minute timeguard is built into the thermostat immediately upon power up, and any time the compressor turns off. The compressor will not turn on until the timeguard has expired. The timeguard affects only compressor operation. Pressing UP and FAN buttons simultaneously will override the timeguard for 1 cycle.

CYCLE TIMER

In normal heating and cooling operation the thermostat will not allow more than 4 equipment cycles per hour (or 1 cycle every 15 minutes). Both the Y and W outputs have a 15-minute timer that starts counting down when the output is turned on, (e.g., if Y output is turned on for 9 minutes and then satisfies, it cannot turn back on for another 6 minutes regardless of demand). However, pressing UP and FAN buttons simultaneously or changing the set point will override the timer for 1 cycle.

MINIMUM ON TIMER

Once the equipment has turned on, it will remain on for a minimum of 3 minutes regardless of demand. However, the equipment can turn off in less than 3 minutes if a change in set point, or a change in mode occurs.

STAGING TIMER

If the thermostat is a heat pump model, it has 2-stage heat capability. In normal operation there is a 15-minute delay between the first and second stages of heat. The Y output will energize first, then 15 minutes later, W is allowed to come on if the thermostat determines it is not satisfying the demand.

However, if the heating demand is greater than 5°, there will be only a 3-minute delay before bringing on W.

ERROR MESSAGES

E4 will be displayed if the thermostat has an internal memory failure. If E4 appears, replace thermostat.

-- (two dashes) will be displayed if the thermostat cannot properly read room temperature. If -- appears, replace thermostat.

Step 5—Check Thermostat Operation

FAN OPERATION

1. Press FAN button. This will start continuous fan operation. FAN ON icon will turn on.
2. Press FAN button again. This will stop continuous fan operation. FAN ON icon will turn off.

HEATING OPERATION

1. Press MODE button until HEAT is displayed.
2. Press UP button until LCD readout reads 3° above room temperature. Press UP and FAN buttons simultaneously to defeat timers. Heating system should begin to operate immediately.
3. For HP thermostats only, press MODE button until EMHT (emergency heat) appears. Press UP and FAN buttons simultaneously to defeat timers. Emergency heating (W is ON, Y is OFF) should begin immediately.

COOLING OPERATION

1. Press MODE button until COOL is displayed.
2. Press DOWN button until LCD readout reads 3° below room temperature. Press UP and FAN buttons simultaneously to defeat timers. Cooling system should begin to operate immediately.




Fig. 2—Typical Air Conditioner

A99114




Fig. 3—Typical Heat Only

A99115




Fig. 4—Typical Heat Pump

A98217




Fig. 5—Two-Zone with Air Conditioner

A99116

***WIRING DIAGRAM NOTES**

1. If "power stealing" connection is used, leave off C connection between thermostat and equipment and add supplied 270 ohm resistor as shown.
2. Supplied 270 ohm resistor **MUST** always be connected between Y1 and C at Two-Zone input as shown.

STANDARD PROGRAMMABLE THERMOSTAT CONFIGURATION RECORD

Date _____

Owner/Operator _____ Thermostat Model No. _____

Indoor Unit Model No. _____ Outdoor Unit Model No. _____

A) Mode Settings

- _____ Hold (On or Off)
- _____ Mode (OFF, HEAT, COOL, EMHT)
- _____ Heating Set Point Value
- _____ Cooling Set Point Value
- _____ Fan (AUTO or ON)

B) Configuration Options

- 1 _____ Anticipator (1-3: factory default = 2)
- 2 _____ N/A
- 3 _____ Fahrenheit or Celsius (F or C: factory default = F)
- 4 _____ Fan On with W (Off or On: factory default = Off)
- 5-9 _____ N/A
- 10 _____ O (reversing valve) On with Heat or Cool (H or C: factory default = C)
- 11-12 _____ N/A
- 13 _____ Room Temperature Offset (-5 to + 5: factory default = 0)

C) Schedule

	MORNING			DAY			EVE			NIGHT		
	TIME	HEAT	COOL	TIME	HEAT	COOL	TIME	HEAT	COOL	TIME	HEAT	COOL
Monday -												
Friday												
Saturday -												
Sunday												

SERVICE TRAINING

Packaged Service Training programs are an excellent way to increase your knowledge of the equipment discussed in this manual, including:

- Unit Familiarization
- Maintenance
- Installation Overview
- Operating Sequence

A large selection of product, theory, and skills programs is available, using popular video-based formats and materials. All include video and/or slides, plus companion book.

Classroom Service Training plus "hands-on" the products in our labs can mean increased confidence that really pays dividends in faster troubleshooting, fewer callbacks. Course descriptions and schedules are in our catalog.

CALL FOR FREE CATALOG 1-800-962-9212

☐ Packaged Service Training ☐ Classroom Service Training